

Mill-Turn 2.0

With Autodesk HSM

Laurens Wijnschenk

Title





About the speaker

Self-taught machinist

Originates from Europe

Customer Advisory group

Active forum member

Going beyond the capabilities

Section Break



Mill-Turn

WHAT DO WE MEAN BY MILL-TURN

SOFTWARES

HSM Family:

- Fusion 360
- Inventor HSM
- HSMWorks

Turning

SETUP


- WCS on rotary-axis
- Spun profile

TEMPLATES

- Templates
- Templates
- Templates

DEVELOPMENT

- Currently in heavy development
- Angelo Juras



DEMO Time



Milling

- Just like a milling machine
- Available for everyone.
- Tool orientation



Milling

	Axial	Radial
Live Tools	Any 2D-3D & Drill	Slot-2D Contour & Drill
Y-axis	Any 2D-3D & Drill	Any 2D-3D & 4-axis & Drill
Multi-task/B-axis	Any 2D-3D & Drill	Any 2D-3D & Drill
	Tilted planes & 5-axis	

DEMO Time



Post processor

SMARTS

- Y-axis/Polar or XZC mode.


GENERIC

- Haas
- Siemens
- Okuma
- Doosan

SETTING UP YOUR MACHINE

- Y-axis
- Axis limits

XYZ-Polar-XZC



Video Time



Machine Configuration

```
description = "HAAS ST-30Y";

var gotYAxis = true;
var yAxisMinimum = toPreciseUnit(gotYAxis ? -50.8 : 0, MM); // specifies the minimum range for the Y-axis
var yAxisMaximum = toPreciseUnit(gotYAxis ? 50.8 : 0, MM); // specifies the maximum range for the Y-axis
var xAxisMinimum = toPreciseUnit(0, MM); // specifies the maximum range for the X-axis (RADIUS MODE VALUE)
var gotBAxis = false; // B-axis always requires customization to match the machine specific functions for doing rotations
var gotMultiTurret = false; // specifies if the machine has several turrets

var gotSecondarySpindle = false;
var gotDoorControl = false;

// >>>> INCLUDED FROM ../common/haas lathe.cps
if (!description) {
  description = "HAAS Lathe";
}
vendor = "Haas Automation";
vendorUrl = "https://www.haascnc.com";
legal = "Copyright (C) 2012-2018 by Autodesk, Inc.";
certificationLevel = 2;
minimumRevision = 40783;

if (!longDescription) {
  longDescription = subst("Preconfigured %1 post with support for mill-turn. You can force G112 mode for a specific operation by usi
}

extension = "nc";
programNameIsInteger = true;
setCodePage("ascii");

capabilities = CAPABILITY_MILLING | CAPABILITY_TURNING;
tolerance = spatial(0.002, MM);

minimumChordLength = spatial(0.25, MM);
minimumCircularRadius = spatial(0.01, MM);
maximumCircularRadius = spatial(1000, MM);
minimumCircularSweep = toRad(0.01);
maximumCircularSweep = toRad(120); // reduced sweep due to G112 support
allowHelicalMoves = true;
allowedCircularPlanes = undefined; // allow any circular motion
allowSpiralMoves = false;
highFeedrate = (unit == IN) ? 470 : 12000;

// user-defined properties
```

```
function defineMachine() {
  machineConfiguration.setVendor("Doosan");
  if (properties.machineType == "PUMA") {
    machineConfiguration.setModel("Puma");
    gotYAxis = true;
    yAxisMinimum = toPreciseUnit(-50, MM); // specifies the minimum range for the Y-axis
    yAxisMaximum = toPreciseUnit(50, MM); // specifies the maximum range for the Y-axis
    xAxisMinimum = toPreciseUnit(0, MM); // specifies the maximum range for the X-axis (RADIUS MODE VALUE)
    gotBAxis = false; // B-axis always requires customization to match the machine specific functions for doing rotations
    bAxisIsManual = true; // B-axis is manually set and not programmable
    gotMultiTurret = false; // specifies if the machine has several turrets
    gotPolarInterpolation = true; // specifies if the machine has XY polar interpolation capabilities
    gotSecondarySpindle = true;
    gotDoorControl = false;
    toolFormat = createFormat({decimals:0, width:4, zeropad:true});
    properties.useG400 = false;
  } else if (properties.machineType == "LYNX") {
    machineConfiguration.setModel("Lynx");
    gotYAxis = false;
    yAxisMinimum = toPreciseUnit(0, MM); // specifies the minimum range for the Y-axis
    yAxisMaximum = toPreciseUnit(0, MM); // specifies the maximum range for the Y-axis
    xAxisMinimum = toPreciseUnit(0, MM); // specifies the maximum range for the X-axis (RADIUS MODE VALUE)
    gotBAxis = false; // B-axis always requires customization to match the machine specific functions for doing rotations
    bAxisIsManual = true; // B-axis is manually set and not programmable
    gotMultiTurret = false; // specifies if the machine has several turrets
    gotPolarInterpolation = true; // specifies if the machine has XY polar interpolation capabilities
    gotSecondarySpindle = true;
    gotDoorControl = false;
    toolFormat = createFormat({decimals:0, width:4, zeropad:true});
    properties.useG400 = false;
  } else if (properties.machineType == "PUMA_MX") {
    machineConfiguration.setModel("Puma MX");
    gotYAxis = true;
    yAxisMinimum = toPreciseUnit(-115, MM); // specifies the minimum range for the Y-axis
    yAxisMaximum = toPreciseUnit(115, MM); // specifies the maximum range for the Y-axis
    xAxisMinimum = toPreciseUnit(-125, MM); // specifies the maximum range for the X-axis (RADIUS MODE VALUE)
    gotBAxis = true; // B-axis always requires customization to match the machine specific functions for doing rotations
    bAxisIsManual = false; // B-axis is manually set and not programmable
    gotMultiTurret = false; // specifies if the machine has several turrets
    gotPolarInterpolation = true; // specifies if the machine has XY polar interpolation capabilities
    gotSecondarySpindle = true;
    gotDoorControl = false;
    toolFormat = createFormat({decimals:0, width:5, zeropad:true});
  }
}
```

DEMO Time





AUTODESK®

Make anything™

Autodesk and the Autodesk logo are registered trademarks or trademarks of Autodesk, Inc., and/or its subsidiaries and/or affiliates in the USA and/or other countries. All other brand names, product names, or trademarks belong to their respective holders. Autodesk reserves the right to alter product and services offerings, and specifications and pricing at any time without notice, and is not responsible for typographical or graphical errors that may appear in this document.

© 2018 Autodesk. All rights reserved.

